




▲ Designate Proper Finish Suffix



see what Delta can doSM

AUXILIARY EXTERIOR CONTROL WITH LED INDICATOR

- Contemporary Round (5CN-120R)
- Transitional Square (5CN-120T)

STANDARD SPECIFICATIONS:

- Surface Mount - 1 1/2" hole required
- Mounts on outside of the steam room and MUST be used with interior interface supplied with the 5P-EST or 5P-ESR generator package
- Control, cable coupler, and strain relief clamp should be mounted 48" above the floor
- Required Electrical Service: Low-voltage connection from steam generator via multi-conductor cable (35' cable included)
- Interface with LED status indicator and Start/Stop button

WARRANTY

- Steam Generators – Lifetime limited warranty; or for commercial purchasers (including for steam bath generators with model numbers beginning with 5COM, which are intended solely for heavy commercial use), one (1) year from the date the product is received by the original purchaser or their authorized representative (installation contractor, etc.).
- Electronic Parts for Steam Bath Generators, Controls, Spa Options and Accessories – two (2) years from the date the product is received by the original consumer purchaser or their authorized representative (installation contractor, etc.); or for commercial purchasers, one (1) year from the date the product is received by the original purchaser or their authorized representative (installation contractor, etc.).
- Please go to www.deltafaucet.com for the complete details of our limited warranty.